
TECHNICAL DATA & FITTING INSTRUCTIONS

VALVE SET A

Tools & Material Required

PTFE tape Allen key - 12mm Spanner - 22mm Adjustable Spanner

Key	Component	Qty
Α	Manual Body (flow)	1
В	Manual Body (return)	1
С	Nut	2
D	Valve Tail (1/2" BSP)	2
E	Compression Fitting (15mm)	2



Assembly Instructions

Apply sufficient PTFE tape to valve tail threads (D), ensuring that tape is wound in a clockwise direction.

Fit valve tails (D) to radiator using 12mm Allen key, ensuring nut (C) is in place. Note: over-tightening of valve tails may cause damage to surface finish of radiator connections. Do not use grips.

Loosen compression fittings (E) and apply valve bodies (A) & (B) to 15mm pipe tails.

Install radiator onto bracket mountings and tighten valve tails (D) onto valve bodies (A) & (B).

Tighten compression fittings (E).

After filling and venting radiator, adjust balancing control to balance radiator.

Further technical information regarding valves (sheet TDS3.1) can be found on our website at **www.bisque.co.uk** or by calling and requesting a faxed or posted copy on **01276 605888**.

